

FURNITURE PAINTS PRODUCT GROUP

Betek Parquet Filling Varnish

DESCRIPTION

Cellulose-based, fast-drying filler varnish.

APPLICATION AREAS

Parquet filler varnish that is used on all types of MDF, chipboard, massive wood and timber cover surfaces to fill the holes and prepare a smooth surface for the top coat. Creates a thick, durable and easy-to-sand layer on the surface.

THINNING

Thin with Betek Cellulosic Thinner by 50% - 100%

APPLICATION

Apply with brush, a roller or a sprayer. Apply 2 or 3 thin coats. Wait for 5-10 minutes after each coat.

DRYING AND SANDING TIME (20°C)

Touch dryness: 10-15 minutes.

Sand dryness: 2 hours.

FLASH POINT

<23°C

CONSUMPTION

Betek Parquet Filling Varnish can varnish 8-10 m². Perform a controlled sample run to estimate the precise consumption.

STORAGE

Store in a cool and well-ventilated environment. Direct sunlight should be avoided. It can be stored for 1 year in its unopened, original package.

PACKAGING

12,5 lt, 2,5 lt,

Hazard statements

H225 Highly flammable liquid and vapour.

H315 Causes skin irritation.

H319 Causes serious eye irritation.

H361d Suspected of damaging the unborn child.

H336 May cause drowsiness or dizziness.

H373 May cause damage to organs through prolonged or repeated exposure.

H304 May be fatal if swallowed and enters airways.

Precautionary statements

P101 If medical advice is needed, have product container or label at hand.

P102 Keep out of reach of children.

P103 Read label before use.

P210 Keep away from heat/sparks/open flames/hot surfaces. - No smoking.

P301+P310 IF SWALLOWED: Immediately call a POISON CENTER/ doctor.

P303+P361+P353 IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing.

Rinse skin

with water/shower.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P405 Store locked up.



P501 Dispose of contents/